

1.	Introduction	3
2.	Realtime IO for Sirius and Cosmo	4
2.1	Principles of Operation	4
2.2	Starting Up the Realtime Video Application	4
2.3	Application Usage.....	5
2.4	Realtime Application Main Window Controls	6
2.4.1	Shuttle Control	6
2.4.2	Immediate Execution Buttons	6
2.4.3	Mode (Direction) of Operation	6
2.4.4	In/Out Point Control.....	7
2.4.5	Clip Data	7
2.4.6	Job Control	8
2.5	The Job List Window	9
2.6	Remote Control Setup for Jaleo PLUS	9
2.7	Remote Control Setup for Jaleo Composite.....	10
2.8	Configuration Files for the Realtime IO Applications.....	10
2.8.1	RtVideo.cfg for Jaleo PLUS	10
2.8.2	RtVideo.cfg for Jaleo Composite.....	10
2.8.3	VLAN.cfg - VLAN Configuration File	11
3.	Jaleo Backup and Restore	13
3.1	The Backup and Restore Applications.....	13
3.2	Principles of Operation	14
3.3	Backup and Restore Details	14
3.3.1	Backup and Restore Setup	15
3.3.2	Backup and Restore Sessions.....	16
3.3.3	Tape Type Configuration File.....	18
4.	File Management Tools	19
4.1	The Dustbin Application	19
4.1.1	The Dustbin and Clip Files	20
4.1.2	The Dustbin and Raw Partition Storage.....	20
4.1.3	Operation and Deletion Options.....	20
4.1.4	Deleting Clip Files without Material.....	21
4.2	The Raw Device Lister Application	21
4.2.1	Start Up	21
4.2.2	Details of the Listing.....	21
5.	Command Line Tools for Raw Partitions.....	23
5.1	Listing Raw Device Contents	23
5.2	Removing Sequences From Raw Devices	23
5.3	Compacting Raw Partitions	23
6.	License Management Tools.....	24
6.1	Introduction	24
6.1.1	Shared Licenses and License Hold Period	24
6.1.2	Manual Interaction	25
6.2	Applications	25
6.2.1	Application Summary	25
6.2.2	License Daemon (jaleolicd)	26
6.2.3	Adding Licenses with AddLicense	26
6.2.4	License Administration with(jlicadmin)	26
6.2.5	License Alerts with (jlicalert).....	26
6.2.6	License Reports with (jlicreport)	27

6.2.7	License Monitoring with (jlicusage)	27
6.2.8	License System Version: (jlicver)	27
6.3	License Troubleshooting	27
6.3.1	No More Licenses	27
6.3.2	No Server for Requested Feature / Cannot Contact Server	27
6.3.3	Server Down	28
6.3.4	Feature Expired	28
6.3.5	Access Conflicts	28
6.3.6	Communication Conflicts	29
6.3.7	Other Errors	29
6.4	License Administration Reference Pages	29
6.4.1	Élan daemon for Jaleo (jaleolicd)	29
6.4.2	Jaleo License Daemon Administration Program (jlicadmin)	31
6.4.3	Alert When a License Becomes Available or Will Expire (jlicalert)	33
6.4.4	Statistics on License Usage (jlicreport)	35
6.4.5	Continuously Report Élan License Activity (jlicusage)	37
6.4.6	Extract Élan Version Information From a Program File (jlicver)	38
6.4.7	elm_resource - Élan Resource File Format	38